

Copyright © 2010 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

4/7/2014

ITEMS NEEDED: PHILLIPS SCREWDRIVER GRIP GLUE BBP#4-136 KNIFE
CLEANING SOLVENT (RUBBING ALCOHOL) SANDPAPER 80 GRIT

NOTE: READ THROUGH ENTIRE INSTRUCTIONS BEFORE STARTING THE INSTALLATION.

1. REMOVE HANDLEBAR WEIGHTS, IF APPLICABLE AND THE HANDLEBAR COVERS WITH A PHILLIPS SCREWDRIVER.
2. REMOVE LEFT GRIP BY EITHER CUTTING IT OFF OR TWISTING IT OFF.
3. REMOVE SCREWS FROM RIGHT HANDLEBAR HOUSING AND DISCONNECT THE TWO CABLES FROM THE THROTTLE SLEEVE. SLIDE RIGHT GRIP OFF HANDLEBAR.
4. CLEAN THE HANDLEBAR ON THE LEFT SIDE OF ANY REMAINING GLUE LEFT BEHIND FROM THE OLD GRIP.
5. WITH ALL THE GLUE REMOVED FROM THE HANDLEBAR LEFT SIDE, LIGHTLY ROUGH THE SURFACE UP WITH SANDPAPER AND THEN CLEAN THE SURFACE WITH A MILD SOLVENT. LIGHTLY ROUGH UP THE INSIDE OF THE LEFT GRIP AND CLEAN.
6. ON THE THROTTLE SIDE (RIGHT) SIMPLY INSTALL THE NEW GRIP BY CONNECTING THE CABLES AND ASSEMBLING THE HOUSING BACK TOGETHER.
7. TEST FIT THE GRIP ON THE LEFT SIDE WITH THE WIRES FROM THE GRIP FACING FORWARD OR DOWNWARD. ALIGN THE GRIP TO MATCH THE POSITION OF THE RIGHT GRIP YOU JUST INSTALLED.
8. APPLY GRIP GLUE EVENLY AROUND HANDLEBAR APPROXIMATELY 2/3 OF THE GRIP LENGTH. CONTINUALLY IN A TWISTING MOTION SLIDE GRIP INTO PLACE ON HANDLEBAR. KEEP GRIP MOVING UNTIL IN DESIRED POSITION, ONCE YOU STOP GLUE WILL IMMEDIATELY HOLD TO HANDLEBAR AND YOU MAY NOT BE ABLE TO REMOVE WITHOUT DAMAGING NEW GRIP.
9. WE RECOMMEND YOU ALLOW GLUE TO CURE FOR 24 HOURS BEFORE USE.
10. WIRE THE FUSED WIRE HARNESS TO THE ACCESSORY TERMINAL IN THE FUSE BOX. (RED GOES TO POSITIVE, BLACK GOES TO NEGATIVE).

NOTE: ON THE 2001-2005 GL1800 THE WIRE HARNESS IS NOT NEEDED. A CONNECTOR UNDER THE RIGHT SIDE PANEL ON THE OEM WIRE HARNESS WILL PLUG DIRECTLY INTO THE CONTROLLER.

11. FIND A PLACE TO MOUNT THE TEMPERATURE CONTROLLER. POSITION THE CONTROLLER SO IT IS EASILY ACCESSIBLE. USE THE DOUBLE-SIDED TAPE PAD TO MOUNT CONTROLLER. CLEAN AREA WITH SOLVENT BEFORE MOUNTING.
12. CONNECT THE TEMPERATURE CONTROLLER TO THE FUSED WIRE HARNESS AND THE GRIPS TO THE TEMPERATURE CONTROLLER. IF NEEDED, USE ZIP TIES (NOT INCLUDED) TO KEEP THE WIRES OUT OF THE WAY.
13. TEST FOR FUNCTION. IT WILL TAKE THE GRIPS A FEW MINUTES TO WARM UP TO FULL TEMPERATURE WHEN TURNED ON. REINSTALL ANY OTHER ITEMS REMOVED.

CAUTION: HEATED GRIPS CAN GET EXTREMELY HOT WHEN USED TO MAXIMUM TEMPERATURE. PLEASE USE CAUTION WHEN USING HEATED GRIPS.

Scan code with your
smartphone to view
video

