

Revised 7/24/2014

ITEMS REQUIRED: FLAT BLADED SCREWDRIVER AND #2 MEDIUM PHILLIPS SCREWDRIVER

INSTALLATION:

1. REMOVE THE FOLLOWING:

A. USING THE FLAT BLADE SCREWDRIVER, PRY OFF THE LEFT AND RIGHT BLACK PLASTIC UPPER SIDE TRIM PIECES (1A) FROM THE LEFT AND RIGHT FAIRING PANEL COVER (1B). **NOTE: EACH SIDE HAS ONE LARGE AND ONE SMALL TRIM PIECE TO BE REMOVED. SET ASIDE.**

B. USING A #2 PHILLIPS SCREWDRIVER, REMOVE THE 3 SCREWS (1C) FROM THE LEFT AND RIGHT LOWER FAIRING PANEL COVERS (1B). SET ASIDE.

2. INSTALL THE LEFT AND RIGHT GRILLES (2A) USING THE 5MM X 30MM SCREWS (2B), SHOW CAPS (2C), AND THE SPACERS (2D) SUPPLIED WITH GRILLES.

