

INSTALLATION INSTRUCTIONS**TRUNK HANDLE
PART # 2-376****HONDA GL1500/6 & GL1800
GOLD WING MODELS**

Revised 2/2/2009

ITEMS REQUIRED: #2 MEDIUM PHILLIPS SCREWDRIVER
MASKING TAPE
SMALL POINT MARKING PEN
ELECTRIC DRILL
1/4" DRILL BIT

1. USING A #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE 4 MACHINE SCREWS (A), 4 FLAT WASHERS (B), AND 4 RUBBER WASHERS (C).
2. COVER THE 4 MOUNTING LEGS (D) OF THE HANDLE (E) WITH MASKING TAPE TO PREVENT SCRATCHES ON THE TRUNK LID (F).
3. CAREFULLY CENTER THE HANDLE (E) ONTO THE REAR OF THE TRUNK LID (F) WITH THE TOP MOUNTING LEGS (D) JUST BELOW THE CURVE (G) ON THE TOP OF THE TRUNK LID (F.)
NOTE: ON GL1800 MODELS THE MOUNTING LEGS OF THE HANDLE NEED TO STRADLE THE MOUNTING LEGS OF THE TRUNK LATCH HOOKS. BE SURE NOT TO DRILL THROUGH THE MOUNTING LEGS.
4. LIFT THE HANDLE (E) SLIGHTLY AND PLACE A 3" TO 4" LENGTH OF MASKING TAPE (H) ONTO THE TRUNK LID (F) UNDER EACH MOUNTING LEG (D).
5. WITH THE HANDLE (E) HELD IN POSITION, AS IN STEP 3, USE A MARKING PEN TO OUTLINE EACH OF THE FOUR MOUNTING LEGS (D) ONTO THE TAPE STRIPS (H).
6. RECHECK THE POSITION OF THE HANDLE (E) AND THE MARKED OUTLINE (RE-MARK POSITION IF NECESSARY) AND SET THE HANDLE (E) ASIDE.
7. USING A CENTER PUNCH AND HAMMER, MARK THE CENTER OF THE FOUR HOLE LOCATIONS (I). USING AN ELECTRIC DRILL, CAREFULLY DRILL FOUR 1/4" DIAMETER HOLES (I) THROUGH THE LID (F).
8. CAREFULLY REMOVE ALL MASKING TAPE (H) FROM THE TRUNK LID AND HANDLE.
9. USING THE #2 MEDIUM PHILLIPS SCREWDRIVER, INSTALL THE HANDLE (E) WITH THE SCREWS (A), STEEL WASHERS (B), AND RUBBER WASHERS (C). NOTE THE STEEL WASHERS (B) ARE ON THE INSIDE OF THE TRUNK LID AND THE RUBBER WASHERS (C) ARE ON THE OUTSIDE, JUST UNDER THE HANDLE (E).

