## **BIG BIKE PARTS' INSTALLATION** INSTRUCTIONS

RADIO SPEAKER COVERS (REAR) **PART NO. 2-487** 

## FOR HONDA GL1500/6 GOLD WING MODELS

Copyright© 1998 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.<sup>®</sup>

Revised 2/4/2009

ITEMS REQUIRED: #2 MEDIUM PHILLIPS SCREWDRIVER INSTALLATION: **REMOVE THE FOLLOWING ITEMS:** A. USING A #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE EIGHT MOUNTING SCREWS (1A) AND BOTH LEFT AND RIGHT ARM REST COVER ASSEMBLIES (1B). NOTE: OPEN THE L/R POCKET COVER DOORS (1C) FOR EASY ACCESS TO THE FRONT INBOARD SCREWS. B. DISCONNECT THE REAR SPEAKER WIRING HARNESS (1D) (IF APPLICABLE) FROM THE RADIO SPEAKERS. NOTE WIRE LOCATIONS. C. USING A #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE EIGHT MOUNTING SCREWS (2A) FROM L/R ARMREST SPEAKER COVERS (2B). USING A #2 MEDIUM PHILLIPS SCREWDRIVER; INSTALL THE CHROME SPEAKER COVERS (2B) USING THE OEM SCREWS (2A) AND 2. WASHERS PROVIDED. USE THE ADDITIONAL FOUR WASHERS PROVIDED TO ACT AS SPACER'S ON THE REAR POSTS TO PREVENT THE OEM SCREWS FROM POKING THROUGH THE COVER. CAUTION: FAILURE TO DO SO MAY CAUSE THE CHROME PLATING TO CRACK WHEN SCREWS ARE TIGHTENED. REINSTALL ALL REMOVED ITEMS BY REVERSING STEPS 1A AND 1B. 3 (2B) SPEAKER FIGURE #2 COVERS (1B) FIGURE #1 SHORT POSTS ARM REST COVERS (1D) SPEAKER WIRING HARNESS ADDITIONAL WASHERS æ Ć (10) ര 6 POCKET 0 0 DOOR WASHERS SCREWS SCREWS SCREWS SCREWS