

BIG BIKE PARTS

INSTALLATION INSTRUCTION FAIRING SIDE LITE HOUSING FOR GL1500/6

Copyright© 2001 by Big Bike Parts, Inc.
No part of this instruction sheet may be
reproduced without the written permission
of Big Bike Parts, Inc.©

PART NO. 52-558

Revised 2/12/2009

ITEMS REQUIRED: #2 PHILLIPS SCREWDRIVER
FLAT BLADE SCREWDRIVER

INSTALLATION:

1. REMOVE LEFT AND RIGHT SIDE COVERS.
2. UNPLUG LIGHT SOCKET FROM SIDE LIGHT HOUSING.
3. PLUG LIGHT SOCKET INTO NEW SIDE LIGHT HOUSING.
4. RE-INSTALL SIDE COVERS.

