

Revised 4/2/2012

TOOLS REQUIRED: 8MM SOCKET WRENCH**CAUTION: ALLOW ENGINE AND EXHAUST SYSTEM TO COOL BEFORE INSTALLING NEW EXHAUST TIPS.**

INSTALLATION:

1. PLACE BIKE ON CENTER STAND.
2. USING 8MM SOCKET WRENCH REMOVE THE 3 SCREWS (ALONG WITH LOCK WASHERS AND FLAT WASHERS) LOCATED ON THE BOTTOM AND INSIDE OF THE OEM EXHAUSTED TIPS.
3. FROM THE REAR OF THE BIKE SLIDE THE OEM EXHAUST TIPS OFF.
4. TO DETERMINE WHICH SIDE THE NEW EXHAUST TIPS FIT ON PLACE THEM NEXT TO EACH OTHER WITH THE MONTING HOLES ON THE BOTTOM AND TO THE INSIDE.
5. INSTALL THE NEW EXHAUST TIPS AND TIGHTEN DOWN USING SCREWS AND WASHERS REMOVED IN STEP #2.

Revised 4/2/2012

TOOLS REQUIRED: 8MM SOCKET WRENCH**CAUTION: ALLOW ENGINE AND EXHAUST SYSTEM TO COOL BEFORE INSTALLING NEW EXHAUST TIPS.**

INSTALLATION:

1. PLACE BIKE ON CENTER STAND.
2. USING 8MM SOCKET WRENCH REMOVE THE 3 SCREWS (ALONG WITH LOCK WASHERS AND FLAT WASHERS) LOCATED ON THE BOTTOM AND INSIDE OF THE OEM EXHAUSTED TIPS.
3. FROM THE REAR OF THE BIKE SLIDE THE OEM EXHAUST TIPS OFF.
4. TO DETERMINE WHICH SIDE THE NEW EXHAUST TIPS FIT ON PLACE THEM NEXT TO EACH OTHER WITH THE MONTING HOLES ON THE BOTTOM AND TO THE INSIDE.
5. INSTALL THE NEW EXHAUST TIPS AND TIGHTEN DOWN USING SCREWS AND WASHERS REMOVED IN STEP #2.