

# BIG BIKE PARTS®

# INSTALLATION INSTRUCTIONS

CHROME INSTRUMENT ACCENT  
PART NO. 52-647

FOR HONDA GL1800 GOLDWING

Copyright© 2002 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

1. FIT CHECK THE PART ON BIKE SO YOU KNOW HOW IT GOES ON.
2. THE PART MAY NEED TO BE TWEAKED. THIS IS DONE BY HOLDING THE EDGES AND GENTLY PRESS THEM UPWARD.  
  
**NOTE: BE VERY CAREFUL, THE PART IS MADE OF PLASTIC AND COULD BREAK EASILY.**
3. USE A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED TO A CLEAN, LINT FREE RAG TO PREPARE THE SURFACE WHERE PART IS BEING APPLIED.
4. THERE IS ONLY ONE CHANCE TO INSTALL THE PART. REMOVE THE BACKING ON ALL PIECES OF TAPE. POSITION THE PART IN PLACE, PRESS THE MIDDLE AREA IN PLACE FIRST AND WORK YOUR WAY TO THE EDGES.
5. THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO PART.

**FAILURE TO INSTALL THIS PART AS PER THE ABOVE INSTRUCTIONS MAY VOID ANY IMPLIED OR WRITTEN WARRANTIES.**