

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

CHROME SIDE FAIRING TRIM FOR GL1800
PART NO 52-682 GOLDWING

Copyright© 2002 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.®

TOOLS: RUBBING ALCOHOL

1. CLEAN THE FINS WITH RUBBING ALCOHOL.
2. PLACE THE 1" WIDE TAPE ON UPPER AND LOWER FINS AND THE 2" TAPE IN THE MIDDLE. (THE PIECES OF TAPE MAY NEED TO BE CUT INTO SHORTER PIECES.