

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2004 by Big Bike Parts, Inc.™ No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.™

FRAME COVERS

PART NO. 52-714 & 52-724

FITS HONDA GL1800

GOLD WING

TOOLS NEEDED: 5MM ALLEN WRENCH

INSTALLATION:

1. REMOVE THE SIDE COVERS.
2. REMOVE THE PLASTIC GRAY PIECE ON THE FRAME THAT COVERS THE WELD. THERE IS A BLACK PLASTIC SNAP RIVET THAT COMES OUT AND THERE IS TAPE HOLDING IT ON.
3. REMOVE THE THREE SCREWS HOLDING THE OEM SWING ARM COVER ON. (THESE SCREWS WILL BE RE-USED.)
4. CLEAN THE FRAME AT THE TOP UNDER THE FAIRING USING RUBBING ALCOHOL.
5. REMOVE THE TAPE BACKING ON THE NEW FRAME COVER. PUT THE COVER ON THE FRAME AND TIGHTEN DOWN RE-USING THE SCREWS REMOVED IN STEP #3.