

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-786

LED TRUNK LIGHTS
GOLDWING GL1800

08/09/12

TOOLS NEEDED: 8MM SOCKET WRENCH

1. USING AN 8MM SOCKET WRENCH, REMOVE THE THREE ACORN NUTS INSIDE THE TRUNK THAT HOLD THE RIGHT TRUNK LIGHT IN PLACE.
2. REMOVE THE RIGHT TRUNK LIGHT FROM THE REAR OF THE BIKE AND REMOVE THE TWO LIGHT BULB SOCKETS FROM THE HOUSING. TO DO THIS TWIST THE SOCKETS COUNTER CLOCKWISE.
3. REMOVING THE WHITE AND BLACK CONNECTOR FROM THE BULB SOCKET MAY SIMPLIFY THIS.
4. REMOVE THE LIGHT BULBS FROM THE SOCKETS BY SIMPLY PULLING THEM STRAIGHT OUT.
5. INSERT THE PLUG ON THE NEW LIGHT INTO THE OUTSIDE BULB SOCKET (THE ONE WITH THE WHITE CONNECTOR) AND INSTALL THE BULB SOCKET INTO THE NEW LIGHT HOUSING. THE INSIDE BULB SOCKET (THE ONE WITH THE BLACK CONNECTOR) WILL REMAIN EMPTY BUT INSTALL IT INTO THE NEW LIGHT HOUSING. THE LED CIRCUIT BOARD ONLY NEEDS THE WHITE CONNECTOR FOR AN INPUT.
6. RECONNECT WHITE CONNECTOR TO OUTSIDE AND BLACK CONNECTOR TO THE INSIDE SOCKETS.
7. TEST THE FUNCTION AT THIS POINT. IF THE LIGHTS DON'T WORK ROTATE THE PLUG 180 DEGREES AND TEST AGAIN.
8. PLACE THE NEW LIGHT INTO THE MOUNTING POSITION ON THE REAR OF BIKE AND INSTALL WITH THE THREE ACORN NUTS REMOVED IN STEP 1. DO NOT OVER TIGHTEN.
9. REPEAT STEPS 1-5 FOR LEFT TRUNK LIGHT.