



INSTALLATION

LED RUN/BRAKE REAR FENDER TIP

3225

PARTS INCLUDED

- 1 Lighted Rear Fender Trim Assembly
- 1 Hardware Kit Containing
 - 1 6 Plug Wire Harness Adapter
 - 4 4" Nylon Cable Ties
 - 1 Dielectric Grease Packet
 - 2 Nylon Cord Keepers
 - 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

TOOLS SUGGESTED

Set of Metric Hex wrenches, Set of Metric Combination Wrenches, Masking tape or Non-Permanent Marker, Cleaning Supplies, Clean Towel

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.



STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

CAUTION! Avoid potential electrical shock! Disconnect the battery before starting this procedure.

STEP 2 Remove the four fasteners that secure the rear license plate panel. Some earlier models may have a fifth fastener behind the license plate. Gently pull off the back panel exposing the wiring harness. (Red and Blue plugs) PIC 1 and PIC 2

-cont.-

3225-21GL-0111



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



kuryakyn.com

STEP 3 Locate the stock wiring plugs, (unplug either the blue or red plugs) and insert the supplied wiring harness in between the stock plugs. PIC 2 One of the two small connectors shown in PIC 3 is where you will be plugging in the light. If you have already installed additional lights in the rear, you may already have an extra connection available to use so you will not need to install the wire harness.

ATTENTION! Küryakyn recommends the use of dielectric grease on electrical connections.

ATTENTION! Thoroughly clean the area of grease, oil, dirt, or other debris to ensure proper adhesion. Küryakyn WILL NOT warranty any parts lost due to improper installation.

ATTENTION! The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 4 Test fit the Fender Accent. Mark the fender panel along the top with a piece of masking tape or non-permanent marker when the bottom edge of the trim is lined up with the bottom edge of the fender. Make sure when test fitting the trim that the wire exits from the bottom of the trim and is not pinched between the trim and the fender.

STEP 5 Remove any grease or debris from the installation area with soapy water and a clean rag; allow the area to dry completely. Clean the rear fender base with the included alcohol cleaning pad to remove any residue and allow the area to dry completely.

STEP 6 Rub the backing on the adhesive strip to activate the adhesive before applying. Remove the adhesive backing. Press the fender trim into place and hold for 1 minute to ensure proper adhesion. Full bond strength will occur within 24 hours.

ATTENTION! Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

STEP 7 Route the wire harness up the inside of the rear fender panel, keeping it away from pinch points. Make sure to check placement of cord keepers so they do not interfere with the frame of the motorcycle when replacing the panel. Clean the fender panel thoroughly where you need to put the included cord keepers and attach them to the inside of the fender panel. Lift the tab on the cord keepers and insert the wire harness. PIC 4

STEP 8 Plug in the harness to the wiring adapter installed in Step 3. Reinstall the rear fender panel to the bike.

STEP 9 Reconnect the battery and test the lights for correct operation.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

