



NACELLE ACCENTS FOR ROAD GLIDE 3780

FITS: '98-UP ROAD GLIDE

PARTS INCLUDED

- 1 Gauge Cover
- 1 Left Large Gauge Pod Trim
- 1 Right Large Gauge Pod Trim
- 1 Left Small Gauge Pod Trim
- 1 Right Small Gauge Pod Trim
- 1 Hardware Kit Including:
 - 2 Alcohol Pads
 - 2 #10 Torx Head Screws
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Torx drivers

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Remove the two screws on the side of the gauges as shown in PIC. 1; these screws will not be used again.

STEP 3 Clean the areas that are highlighted in PIC. 2 with the included alcohol cleaning pads and allow them to dry.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT warranty any parts lost due to improper installation.

-cont.-



CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

· Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

· The product must be properly installed, maintained and operated under normal conditions.

· Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

· Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in non-conforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

· Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

· Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.

· Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50° F. Do not attempt this installation in temperatures less than 50° F.

STEP 4 Using the back of your fingernail, rub the adhesive backing of the two adhesive strips on the backside of the gauge cover to activate the catalyst.

STEP 5 Remove the backing and place the gauge cover in place, secure with the two Torx head screws from the hardware kit.

STEP 6 Refer to [PIC. 3](#) to determine the large left trim piece.

STEP 7 Using the back of your fingernail, rub the adhesive backing of the strips on the backside of the large left trim piece to activate the catalyst.

STEP 8 Remove the adhesive backing and install the trim piece, press and hold for one (1) minute, full bonding strength will occur in 24 hours.

STEP 9 Repeat STEP 6 through Step 8 for the right side.

STEP 10 Refer to [PIC. 3](#) to determine the small left trim piece.

STEP 11 Using the back of your fingernail, rub the adhesive backing of the strips on the backside of the small left trim piece to activate the catalyst.

STEP 12 Remove the adhesive backing and install the trim piece; place the front of the trim in place first as shown in [PIC. 4](#), then press the back portion of the trim in place.

STEP 13 Repeat STEP 10 through Step 12 for the right side.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

Ride On!

