

# INSTALLATION

## TANK TRIM WITH SCUFF PROTECTION 3916

FITS: ALL '01-UP GL1800 MODELS

#### **PARTS INCLUDED**

- 1 Right Side Tank Trim Assembly
- 1 Left Side Tank Trim Assembly
- 2 Alcohol Pads
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

### THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

#### **PROCEDURE**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**STEP 2** Determine the left and right side tank trim (PIC 1).

**STEP 3** Test fit the tank trim to the fuel tank area (PIC 2).

**NOTE** The tank trim is contoured to fit the panel. It may take multiple test fitments to find the best fit on the panel.

**STEP 4** Temporarily mark the location of the tank trim using masking tape.

**STEP 5** Remove the tank trim from the motorcycle and clean the mounting area with a supplied alcohol pad.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.







#### **CUSTOMER SERVICE**

877.370.3604 (toll free)

## **INSTALLATION QUESTIONS**

techsupport@kuryakyn.com or call 715.247.2983

#### **LIMITED WARRANTY**

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, naintained and operated under normal conditions.
- Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.
  - Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Küryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

#### **ABOUT OUR CATALOG**

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today-select the "CATALOGS" icon. Each Küryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved



**STEP 6** Rub the adhesive backing to activate the adhesive. Remove the tape backing and apply the tank trim to the fuel tank using the markings made in Step 4 as a guide.

**STEP 7** Push evenly on all edges and center of the tank trim to assure proper adhesion. Hold in place for one minute, full bonding strength will occur in 24 hours.

**STEP 8** Repeat all steps for the opposite side and make sure the Tank Trim is properly adhered to the panel.

Ride On!



PAGE 2