

# **INSTALLATION**

# **REAR SMOKE LENS KIT**

4995

#### **PARTS INCLUDED**

- Red L.E.D. Wedge Bulb
- 2 Turn Signal Smoke Lens — Flat-Pancake
- Smoke Lens for Rear Fender 1
- 2 Red Incandescent Turn Signal Bulb
- **Installation Instructions** 1

Please read and understand entire instructions before starting installation.

#### THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN

POTENTIAL DEATH OR SERIOUS INJURY.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

## **TOOLS SUGGESTED**

Phillips Head Screwdriver, Small Flat Blade Screwdriver

### STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

- STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.
- STEP 2 Remove your OEM turn signal lenses using a Phillips screwdriver. Remove the OEM turn signal bulbs.
- STEP 3 Install the supplied Red Incandescent Turn Signal Bulb and Smoke Lens in the reverse fashion as the OEM lenses and bulbs were removed.
- STEP 4 USE CAUTION ON THIS STEP. IF NOT CAREFUL, YOU MAY SCRATCH THE CHROME TRIM. Remove your OEM fender tip lens by using a small flat head screwdriver. Insert the tip of the screwdriver into the notch between the top edge of the lens and the chrome trim around the lens. Gently lift the screwdriver upward, pushing the tab of the lens down releasing the lens.

#### **CUSTOMER SERVICE**

877.370.3604 (toll free)

## **INSTALLATION QUESTIONS**

techsupport@kuryakyn.com or call 715.247.2983

#### LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- · Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - •The product must be properly installed, maintained and operated under normal conditions.
  - •Küryakyn makes no warranty, expressed or implied, with respect to any gold plated
- •Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Kürvakvn and a customer.
- •Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kürvakvn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to: control modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer1s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

#### **ABOUT OUR CATALOG**

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved



Küryakyn

**STEP 5** Remove the stock bulb and insert the Red LED Wedge Bulb. Before replacing the lens test for

function. If the Red LED Wedge Bulb does not light, remove it, rotate 180 degrees and reinsert it.

Test for function.

**STEP 6** If bulb functions well, install the Smoke Lens.

WARNING! ENSURE PROPER TURN SIGNAL AND RUNNING LIGHT OPERATION BEFORE

RIDING THE MOTORCYCLE. VISIBILITY IS A MAJOR CONCERN FOR MOTORCYCLISTS. A TURN SIGNAL OR RUNNING LIGHT MALFUNCTION

COULD RESULT IN DEATH OR SERIOUS INJURY.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including

pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance

may be required.

Ride On!

PAGE

2