



LOWER LEG DEFLECTOR SHIELDS—BLACK

7209

PARTS INCLUDED

- 1 Right Side Lower Leg Deflector Shield—Black
- 1 Left Side Lower Leg Deflector Shield—Black
- 1 Right Side Fender Mount Accent—Black
- 1 Left Side Fender Mount Accent—Black
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

NOTE: Pictures shown are of chrome parts. Installation of Black parts will be the same.

STEP 2 Clean the lower fork leg (PIC 1) and fender mount thoroughly using a mild soap and warm water, making sure to remove all contaminants. Failure to clean this surface will result in poor adhesion. Rinse and dry the area completely.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 3 As shown in PIC 2, test fit the Fender Mount Accent to the front fender mount boss. The accents are marked left and right. Mark the location of best fit with masking tape to aid in final installation.

STEP 4 Test fit the Deflector Shield to the lower fork leg, note that there is a Left and Right side Deflector Shield. Make sure that mounting the Deflector shield will not interfere with the Fender Mount Accent. Mark the location of best fit with masking tape to aid in final installation.

-cont.-

7209-21HD-0811

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
 - Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 5 Clean the mounting area of the lower fork leg and fender mount with the supplied alcohol pad, dry the area completely with a clean cloth.

STEP 6 Rub the adhesive backing on the Fender Mount Accent to activate the adhesive. Remove the tape backing and apply over the fender mount using any markings made in Step 3 as a guide.

STEP 7 Press and hold the Fender Mount Accent in place for one full minute, full bonding strength will occur in 24 hours.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 8 Rub the adhesive backing on the Deflector Shield to activate the adhesive. Remove the tape backing and apply the Deflector Shield to the lower fork legs using the markings made in Step 4 as a guide. Check that there is no interference between the Deflector Shields and the Fender Mount Accents.

STEP 9 Press and hold the Deflector Shield in place for one full minute, full bonding strength will occur in 24 hours.

STEP 10 Repeat all steps for the fork leg on the opposite side.

