



INSTALLATION

ENGINE CASE COVERS

7704

PARTS INCLUDED

- 1 Right Cylinder Base Cover — Chrome
- 1 Left Cylinder Base Cover — Chrome
- 1 Right Lower Cylinder Base Cover — Chrome
- 1 Front Mount Spacer — Chrome
- 1 Rear Mount Spacer — Chrome
- 1 Hardware Kit including the Following:
 - 3 #10-24 X 1/2" Button Socket Cap Screw — Chrome
 - 1 1/4"-20 X 6" Socket Head Cap Screw — Chrome
 - 1 #10-24 X 5/8" Phillips Head Pan Screw
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Metric and Standard Hex Wrenches, Metric Hex Sockets and Torque Wrench, Phillips Head Screwdriver

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY

NOTE: For some models, loosening the exhaust where the pipes fasten to the heads and on lower brackets may be necessary to gain clearance to install the engine case covers.

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
 - Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



-cont.-

7704-21MC-0911

kuryakyn.com

- STEP 2** Using a hex wrench, remove the fastener that secures the master cylinder to the frame. The master cylinder is located under the front exhaust pipe on the right side of the bike. See PIC.1.
- STEP 3** Using two of the supplied #10-24 X 1/2" Button Socket Cap Screws, Secure the Right Lower Cylinder Base Cover (labeled as C in FIG.1) to the Right Cylinder Base Cover (labeled as D in FIG.1).
- STEP 4** Using the supplied #10-24 X 5/8" Phillips Head Pan Screw, secure the Rear Mount Spacer (labeled as B in FIG.1) to the Right Cylinder Base Cover (labeled as D in FIG.1).
- STEP 5** On the right side of the bike, remove the two OEM fasteners shown in PIC.2. Then maneuver the Right Cylinder Base Cover into position on the engine case.
- STEP 6** Loosely reinstall the two OEM fasteners removed in STEP 4 through the mounting tabs on the Right Cylinder Base Cover.
- STEP 7** On the left side of the bike, remove the two OEM fasteners shown in PIC.3 and maneuver the Left Cylinder Base Cover into position on the engine case.
- STEP 8** Loosely reinstall the two OEM fasteners removed in STEP 6 through the mounting tabs on the Left Cylinder Base Cover.
- STEP 9** Using the remaining supplied #10-24 X 1/2" Button Socket Cap Screw, loosely secure the Left Cylinder Base Cover (labeled as A in FIG.1) to the Rear Mount Spacer (labeled as B in FIG.1).
- STEP 10** Slide the supplied 1/4"-20 X 6" Socket Head Cap Screw through the fastener hole at the front of the Right Cylinder Base Cover (labeled as A in FIG.1) and the Front Mount Spacer (labeled as E in FIG.1). Then thread it into to the Right Cylinder Base Cover (labeled as D in FIG.1). Do not tighten fully at this time.
- STEP 11** Tighten the fasteners in the specific order outlined below:
- Tighten the OEM fasteners that were loosely installed in STEP 5 and STEP 7, to 10 foot-pounds of torque.
 - Snuggly tighten the 10-24 X 1/2" Button Socket Cap Screw that was loosely installed in STEP 8.
 - Tighten the 1/4"-20 X 6" Socket Head Cap Screw loosely installed in STEP 9.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

