



BOOMERANG FRAME COVERS 7773

PARTS INCLUDED

- 1 Right Side Boomerang Frame Cover
- 1 Left Side Boomerang Frame Cover
- 2 Swingarm Nut Covers
- 4 10-32 Set Screws
- 2 Alcohol Pads
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of Torx Wrenches, Set of Hex Wrenches, Combination Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE - BIKES WITHOUT SADDLEBAGS (saddlebag models see page 2)

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 As shown in PIC 1, test fit the boomerang covers to the frame. On bikes without saddlebags, the covers should fit without removing any hardware or peg mounts.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 3 Clean the mounting area on the frame thoroughly with a mild soap and water. Rinse the area and dry completely. Test fit the boomerang cover to the frame again and adjust the cover as desired to find the best fit.

CUSTOMER SERVICE
877.370.3604 (toll free)

INSTALLATION QUESTIONS
techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
 - The product must be properly installed, maintained and operated under normal conditions.
 - Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Küryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Küryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA® All Rights reserved.



ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 4 Mark the area of best fit using masking tape. This will help for final installation. Clean the mounting area with the included alcohol pads and dry completely.

STEP 5 Remove the tape backing and apply the boomerang cover to the frame using any markings made in Step 4 as a guide. Press and hold the boomerang cover in place for one minute. Full bonding strength will occur in 24 hours.

STEP 6 Make sure the set screws are threaded in to the swingarm nut covers. Place the nut cover in place (PIC 2) and tighten the set screws to lock the nut covers in place. Repeat all steps for the opposite side.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

FOR BIKES WITH SADDLEBAGS

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 As shown in PIC 1, test fit the boomerang covers to the frame. Remove the saddlebag support bracket and passenger peg mount from the frame. These will be re-installed.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 3 Clean the mounting area on the frame thoroughly with a mild soap and water. Rinse the area and dry completely. Test fit the boomerang cover to the frame again and adjust the cover as desired to find the best fit.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 4 Mark the area of best fit using masking tape. This will help for final installation. Clean the mounting area with the included alcohol pads and dry completely.

STEP 5 Remove the tape backing and apply the boomerang cover to the frame using any markings made in Step 4 as a guide. Press and hold the boomerang cover in place for one minute. Full bonding strength will occur in 24 hours.

STEP 6 Make sure the set screws are threaded in to the swingarm nut covers. Place the nut cover in place (PIC 2) and tighten the set screws to lock the nut covers in place.

STEP 7 As shown in PIC 3, replace the saddlebag support bracket and passenger peg mount over the top of the boomerang cover. Tighten all hardware. Repeat all steps for the opposite side.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.

Ride On!

Küryakyn[®]

PIC. 1



PIC. 2



PIC. 3



PAGE

2