

# **INSTALLATION**

# **SWITCH HOUSING COVER**

7827

### **CUSTOMER SERVICE**

877.370.3604 (toll free)

# **INSTALLATION QUESTIONS**

techsupport@kuryakyn.com or call 715.247.2983

sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - maintained and operated under normal conditions.
  - implied, with respect to any gold plated
- consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Kürvakvn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- •Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Küryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to: control

### **ABOUT OUR CATALOG**

Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other accessories designed for riders by riders.

# LIMITED WARRANTY Küryakyn warrants that any Küryakyn products

- · Küryakyn shall have no obligation in the event
  - •The product must be properly installed,
  - Kürvakvn makes no warrantv, expressed or
- •Küryakyn shall not be liable for any
- modules, wiring, chrome & other components.
- •Küryakyn makes no warranty of any kind in regard to other manufacturer1s products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

For purchasing Küryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Küryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for

Küryakyn® products, the motorcycle parts and

©2005 Küryakyn USA® All Rights reserved.

# **PARTS INCLUDED**

- Right Top Cover 1
- 1 Left Top Cover
- 1 Bottom Right Cover
- 1 Bottom Left Cover
- 1 Hardware Kit Including:
  - Adhesive Foam Pads
  - #4-40 x 1/2" Socket Head Cap Screws (SHCS)
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

# THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and

functionality.

# **CAUTION!**

This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material

damage.

# **TOOLS SUGGESTED**

Set of Hex Wrenches

# STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

# STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ianition.

NOTE: For best appearance, motorcycle must be equipped with Küryakyn Handlebar Control Dress-Up Kits (P/N 9119 or 9126) or H-D Handlebar

Reservoir Cover Sets (H-D P/N 46099-98 or 46098-98)

### STEP 2 Using the back of your

fingernail, rub the brown adhesive backing on two foam pads to activate the catalyst, remove the backing and install the adhesive foam pads on the inside of the top covers as

shown in PIC 1.

PIC 1

7827-22HD-0711

-cont.-





UPPER RIGHT

LOWER

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT warranty any parts lost due to improper installation.

**ATTENTION!** The adhesive will not bond correctly if applied at temperatures less than 50° F. Do not attempt this installation in temperatures less than 50°F.

STEP 3

Test fit the left upper and lower covers on the left switch housing (referring to PIC. 2 to determine the left covers).

NOTE: The covers are designed to have a small amount of movement when they are installed; if there is too much play, you can install an additional foam pad on the inside of the top cover.

PIC 2

UPPER LEFT

IOWER LEFT

STEP 4

Once the proper fit has been achieved, secure the top and bottom cover together using three screws from the hardware kit (two screws for the right side).

NOTE: You may choose to remove the adhesive backing on the foam pad that was installed on the cover before securing the top and bottom together.

STEP 5 Repeat STEP 3 and STEP 4 for the right side.

STEP 6

Check for clearance between the throttle grip and the cover, the throttle needs to operate freely; if it doesn't move freely, remove the cover and adjust the foam pads until the throttle will operate freely.

STEP 7

Test to make sure that all the switches and levers operate freely before riding the motorcycle.

**CAUTION!** 

Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

Ride On!

**ATTENTION!** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

**PAGE**