



# INSTALLATION



## UNDERSEAT PASSENGER PEG MOUNTS 7960

**CUSTOMER SERVICE**  
877.370.3604 (toll free)

**INSTALLATION QUESTIONS**  
techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



**FITS: '86-UP SOFTAIL MODELS (EX. '00-UP DEUCE AND '06-UP SOFTAIL STANDARD, NIGHT TRAIN OR SOFTAIL SPRINGER).**

### PARTS INCLUDED

- 2 Under Seat Peg Mount Assembly with Clevis
- 1 Hardware Kit Including:
  - 4 3/8-16 x 1" SHCS
  - 1 Anti-Seize
  - 2 Hot Spots
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

### THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**ATTENTION!** Be sure to use the supplied anti-seize on all threaded fasteners before installation. This will reduce galling and make future removal of the fasteners easier.

### PROCEDURE

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition.

**STEP 2** Remove the two Torx head fasteners at the front of each fender strut.

**NOTE** Determine the position of the clevis angle. Adjust the clevis to the desired angle and secure with the 5/16-18 x 1" bolt on the back of the bracket assembly.

**STEP 3** There is a distinct left and right bracket. Orient the footpeg toward the front of the bike with the bracket mounting holes above it. Position the mount assembly on the corresponding strut.

**STEP 4** Mount the assemblies to the frame with the provided 3/8"-16 x 1" socket head cap screws. Tighten securely.

**-cont.-**

**STEP 5** Remove the 3/8" clevis cross bolt from the clevis. Install the male mount footpeg of your choice and the wave washer. Re-install the cross-bolt and tighten.

**CAUTION!** Prevent potential injuries! Verify all fasteners are secure before riding.

**ATTENTION!** It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

**Kuryakyn**

*Ride On!*

**PAGE**

**2**

**PASSENGER PEG MOUNTS**

**INSTALLATION**