BIG BIKE PARTS INSTALLATION INSTRUCTIONS Copyright[©] 2019 by Big Bike Parts, Inc. No part of this PART NO. 52-936, 52-936BK TOUR RACK instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc. FITMENT: HONDA GOLDWING TOUR 2018-NEWER 1/4/2019 TOOLS NEEDED: 5/16" DRILL BIT 4MM ALLEN WRENCH **REMOVABLE THREAD LOCK** DRILL MASKING TAPE PENCIL/MARKER PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. *USE REMOVABLE THREAD LOCKER ON ALL FASTENERS* ESTIMATED INSTALLATION TIME: 30 TO 45 MIN. NOTICE INSTALLATION: DO NOT EXCEED THE LOAD CAPACITY THAT IS SPECIFIED BY THE VEHICLE MANUFACTURER, EXCESSIVE LOADING ON THE TRUNK LUDGAGE RACK MAY CAUSE LOSS, DAMAGE TO THE MOTORCYCLE OR INJURY, BIG BIKE PARTS IS NOT RESPONSIBLE FOR LOSS, DAMAGE OR INJURY CAUSED DUE TO EXCESSIVE LOADS OVER THE VEHICLE MANUPACTURER'S LOAD SPECIFICATIONS ON THE LUGGAGE RACK. CLEAN THE TRUNK LID. 1. USING A TAPE MEASURE FIND THE CENTER OF THE TRUNK LID. USE MASKING TAPE TO MARK 2. THE CENTER LINE. SEE FIG.1. HOLD THE RACK ABOVE THE TRUNK LID IN THE POSITION YOU WISH TO MOUNT IT. USE THE 3. CENTER LINE MARK AS REFERENCE POINT. PLACE FOUR PIECES OF MASKING TAPE ON THE TRUNK LID WHERE THE LEGS WILL TO BE. SEE FIG. 1. 4. 5. SET THE RACK ON THE TRUNK LID WITH THE LEGS RESTING ON THE MASKING TAPE. CAREFULLY CHECK THE ALIGNMENT OF THE RACK. SEE FIG. 2. USING A MARKER CIRCLE AROUND THE BOTTOM OF EACH LEG ON THE MASKING TAPE. SEE FIG. 3. 6. REMOVE THE RACK AND MARK THE CENTER OF EACH CIRCLE AS SHOWN IN FIG. 4. MEASURE THE MARKS TO MAKE SURE THEY ARE CENTERED. 7. USE A 5/16" DRILL BIT TO DRILL A HOLE ON EACH CENTER MARK THROUGH BOTH LAYERS OF THE TRUNK. 8. 9. REMOVE THE MASKING TAPE AND ANY BURRS. REMOVE THE RUBBER COVERS ON THE LEGS OF THE RACK. 10. INSTALL THE RACK TO THE TRUNK USING THE SUPPLIED HARDWARE AS SHOWN IN FIG. 5. 11. ROTATE THE ANGLED SPACERS TO BEST FIT THE TRUNK LID AS YOU TIGHTEN EACH OF THEM. INTE TAPE -FIG. 2 FIG. 1 MARH MARK FIG. 4 FRONT RUBBER ANGLED SPACER WASHER THICKER TRUNK ANGLED RUBBER SPACER WASHER ANGLED SPACER THICKER ANGLED FIG. 5 SPACER