



# INSTALLATION

## LIGHTED LOWER SADDLE BAG ACCENT

# 1564

### PARTS INCLUDED

- 1 Right Lighted Saddlebag Accent
- 1 Left Lighted Saddlebag Accent
- 1 Hardware Kit Including:
  - 5 Alcohol Pads
  - 6 Cable Ties
  - 1 Dielectric Grease Pack
  - 6 T-Tap Female Quick Slide Scotchlocks
  - 6 Male Scotchlocks
  - 1 Wiring Pigtail
  - 2 Warning Stickers
  - 8 Cord Keepers
  - 2 Bumpers
  - 1 Y-adapter (for 2010-up Road Glide and Street Glide models only)
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

### THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

### TOOLS SUGGESTED

Set of combination wrenches, warm soapy water and a clean, straight edges (rulers, paint sticks,) masking tape, wire strippers, test light

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**WARNING!** YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

-cont.-

1564-22HD-1010



### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
  - The product must be properly installed, maintained and operated under normal conditions.
  - Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

• Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

• Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

• Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.

• Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge.

Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025.

Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



kuryakyn.com

**STEP 2** Remove the saddlebags from the motorcycle and set them on a clean towel or blanket on a stable surface.



**CAUTION!** Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

**STEP 3** Clean the bottom of the saddlebags with warm soapy water and a clean rag; rinse and allow them to dry.

**STEP 4** Refer to PIC 1 to determine the left accent.

**STEP 5** Place the left trim piece on the bottom of the left saddlebag.

**STEP 6** Using straight edges on the outside of the saddlebag, as shown in PIC 2 (A), use an additional straight edge and make sure you have approximately 1" extending over on the rear of the bag. PIC 2 (B) This will create the best view of the light.




**STEP 7** Once the accent piece has been properly located on the saddlebag, mark several locations along the edge of the accent with masking tape for points of reference as shown in PIC 3.

**STEP 8** Remove the accent piece and clean the bottom of the saddlebag using an included alcohol-cleaning pad and let the area dry.

**ATTENTION!** Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT warranty any parts lost due to improper installation.

**ATTENTION!** The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.




**STEP 9** Using the back of your fingernail, rub the backing of the adhesive pads to activate the adhesive.


**STEP 10** Remove the adhesive backing and place the accent piece in position, lining up the edges with the masking tape reference points.

**STEP 11** Press and hold accent piece in place for one (1) minute, full bonding strength will occur in 24 hours.

**STEP 12** Using the back of your fingernail, rub the adhesive backing of the bumper; remove the backing and install on the front corner of the saddlebag as shown in PIC 4.



**STEP 13** Locate the routing pattern for the wires from the accent along the inner portion of the saddlebag. The wires need to be routed so that they are away from extreme heat, moving parts or pinch points. PIC 5 shows a suggested routing for the wires.



**Note:**  
These locations are only suggested points to place the cord keepers & wires. You may need to place them in different locations for proper clearance.

**STEP 14** Referring to PIC 5, clean the highlighted areas with the included alcohol cleaning pad and allow the areas to dry.


**STEP 15** Using the back of your fingernail, rub the adhesive backing on the cord keepers to activate the adhesive. Remove the adhesive backing, press and hold each cord keeper in place for one (1) minute, full bonding strength will occur in 24 hours.

**STEP 16** Place the wires from the accent in the cord keepers, and then close the keepers, ensuring that they snap closed.

**STEP 17** Reinstall the left saddlebag on the motorcycle.

**STEP 18** Repeat STEP 4 through STEP 17 for the opposite side.

**STEP 19** Remove the seat from the motorcycle and locate the main taillight harness as shown in PIC 6.



**Note:** For '93-'96 models, it will be necessary to hardwire the lights, skip to STEP 26 under the wiring procedure for '93-'96 section.

**Note:** For '10-up Road Glides & Street Glides, skip to STEP 39. The Y-adapter is required for installation.

**STEP 20** Disconnect the wiring harness. Place a small amount of dielectric grease on the 8-pin connections from the main taillight wiring harness and plug the pigtail into the ends of the main taillight harness.

**Note** **If there is a run-turn-brake controller installed, the pigtail harness needs to be installed upstream (in front) of the controller.**

**ATTENTION!** Kuryakyn recommends the use of dielectric grease on electrical connections.

**STEP 21** Route the wires from the saddlebags under the seat. Use the included cable ties to secure the wires away from pinch points, extreme heat or moving parts.


**STEP 22** Apply a small amount of dielectric grease to the connections from the accent pieces.

**STEP 23** Plug the wires from the accent into the 3 pin pigtails from the main pigtail harness.

**STEP 24** Turn the ignition on and test to make sure that the lights function as both running lights and brake lights.

**STEP 25** Place the warning stickers on the inside of the bags as shown in PIC 7 to serve as a reminder to prevent the wires from being damaged when the saddlebags are removed from the motorcycle.

**ATTENTION!** **It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.**



## Wiring Procedure for '93-'96 Models

**STEP 26** Cut the three-pin pigtails from the supplied pigtail harness as close to the connection point as possible (shown in PIC 8.)

**STEP 27** Using wire strippers remove a small amount of insulation from the cut ends of the wires.

**STEP 28** Insert the exposed end of one wire into a male scotchlock and crimp the end making sure that the wire is secure, as shown in PIC 9



**STEP 29** Repeat STEP 28 for the rest of the wires from the 3-pin pigtails.

**STEP 30** Expose the main taillight wiring harness's wires.

**STEP 31** Place two female T-Tap connectors over the black, red and blue wires in the main taillight wiring harness; close the connectors ensuring that the tabs are engaged as shown in PIC 10.

**STEP 32** Place a small amount of dielectric grease on the female T-Tap connectors; insert the male spade connectors from the black wires into the female T-Tap connectors that were installed on the black wires in the taillight harness.

**STEP 33** Repeat STEP 32 for the red and blue wires, connecting the red wires to the red wire and the blue wires to the blue wire.



**ATTENTION!** Kuryakyn recommends the use of dielectric grease on electrical connections.

-cont.-


**STEP 34** Route the wires from the saddlebags under the seat, use the included cable ties to secure them away from pinch points, extreme heat or moving parts.

**STEP 35** Apply a small amount of dielectric grease to the connections from the accent pieces.

**STEP 36** Plug the 3-pin connector from the accent into the 3 pin pigtails that were hardwired to the taillight harness.

**STEP 37** Turn the ignition on and test to make sure that the lights are function as both running lights and brake lights.

**STEP 38** Place the warning stickers on the inside of the bags as shown in PIC 7 to serve as a reminder to prevent the wires from being damaged when the saddlebags are removed from the motorcycle.



**Wiring Procedure for '10-up Road Glide Customs & Street Glides: Y-Adapter**


**STEP 39** With the saddlebags still removed from the bike, remove the left side cover to expose the wiring harness.

**STEP 40** Attached to the wiring harness is a separate wiring harness that is not being used. (The lead is about 2' in length when un-coiled) PIC 11

**STEP 41** Place a small amount of dielectric grease on the separate wiring harness plug.

**STEP 42** Place the male (bike plug) end into the female Y-adapter plug of the new 3-pin Y-adapter.

**STEP 43** Remove the seat to provide proper space to route the adapter wire to the right side of the bike. Secure the wire so it will not get pinched or snagged on anything under the seat.



**ATTENTION!** Secure all wiring away from any moving parts, pinch points or extreme heat. Kuryakyn WILL NOT warranty any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

**STEP 44** Mount the right saddle bag to the bike and hook up the wires from the bag to the bike.

**STEP 45** Test mount the left saddlebag to determine how much of the Y- adapter plug wire you will need to replace the side cover. Once you are satisfied with the amount of wire, tie up any access and replace the side cover and mount the saddlebag. Connect the saddlebag light to the Y-adapter plug.

**ATTENTION!** Kuryakyn recommends the use of dielectric grease on electrical connections.

**STEP 46** Turn the ignition on and test to make sure that the lights function as both running lights and brake lights. If they do not function, check all wiring connections.

**STEP 47** Replace the seat after all wires have been secured.

**STEP 48** Turn the ignition on and test to make sure that the lights are function as both running lights and brake lights.

**STEP 49** Place the warning stickers on the inside of the bags as shown in PIC 7 to serve as a reminder to prevent the wires from being damaged when the saddlebags are removed from the motorcycle.

*Ride On!*