



TRANSFORMER BACKREST MOUNTING STRAPS 1633

FITS: ALL '02-'08 VTX 1800 R/S/V/F MODELS, ALL '03-UP VTX 1300 R/S/C MODELS FOR MOUNTING TRANSFORMER BACKREST (P/N 1606) ONLY

CUSTOMER SERVICE 877.370.3604 (toll free)

INSTALLATION QUESTIONS techsupport@kuryakyn.com or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer...

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
• The product must be properly installed, maintained and operated under normal conditions.
• Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
• Kuryakyn shall not be liable for any consequential and incidental damages...
• Kuryakyn products are often intended for use in specific applications...
• Kuryakyn electrical products are warranted for one (1) year from the date of purchase...

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today-select the "CATALOGS" icon. Each Kuryakyn® product comes with a Proof-of-Purchase good for a complimentary catalog.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.

PARTS INCLUDED

- 1 Right Side Mounting Strap
1 Left Side Mounting Strap
1 Hardware Kit including:
2 M10 x 1.25 x 50mm Socket Head Cap Screw
2 M10 x 1.25 x 55mm Socket Head Cap Screw
4 Spacer, .433 ID X .669 OD, .512 L
4 M10 X 1.5 Acorn Nut, 18-8 SST, Chrome
2 M10 X 1.25 X 53.5 Custom Head FSCS, 18-8 SST
1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KURYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches, set of combination wrenches or socket set.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Beginning on the left side of the motorcycle, remove stock strut mounting hardware. Set the bolts aside, they will not be used again.

STEP 3 Insert two spacers into the holes in the left strut. See PIC 1.



STEP 4 Insert one of the 55mm bolts through the front hole on the left Backrest Mounting Strap plate. See FIG 1.

STEP 5 While securing the Mounting Strap plate, insert the bolt through the spacer and begin threading it into the strut. See PIC 2.

STEP 6 Insert a 50mm Bolt through the rear hole in the Mounting Strap plate and spacer; finger tighten both bolts.


STEP 7 Repeat Steps 2 through 6 for the right side; finger tighten the bolts at this time.

STEP 8 Install the backrest bar (not included) into the Mounting Straps as shown in PIC 3; secure backrest bar to Mounting Straps with fasteners (not included). Finger tighten at this time.

NOTE: With the fasteners loosely installed, adjust the Backrest Mounting Strap plates to accommodate the backrest bar.


STEP 9 Tighten all fasteners and check for proper clearance and operation.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.



PIC 1

FIG 1



INSERT 55 MM BOLT THROUGH MOUNTING STRAP PLATE AND SPACER, THREAD THE BOLT FAR ENOUGH TO SUPPORT ONE END OF THE MOUNTING STRAP PLATE.

50 MM BOLT HOLE

BACKREST MOUNTING STRAP WITH ADJUSTMENT BRACKET INSTALLATION

STEP 1 Park the motorcycle on a hard, level surface; shut off the ignition and allow the engine to cool.

STEP 2 Beginning on the left side of the motorcycle, remove stock strut mounting hardware. Set the bolts aside, they will not be used again.

STEP 3 Insert a 55mm bolt through the adjustment bracket and spacer into the front hole in the left strut. See PIC 4 and FIG 2. Begin to thread the bolt in enough to support one side of the bracket.



PIC 2



PIC 3

SECURE THE BACKREST TO THE MOUNTING STRAPS


STEP 4 Insert a M10 X 1.25 X 53.5 Custom Head bolt into the adjustment bracket rear hole, through a spacer and into the hole in the left strut; finger tighten. See PIC 5.

STEP 5 Place the left Backrest Mounting Strap plate over the protruding studs on the adjustment bracket. Secure with two acorn nuts; finger tighten at this time.

STEP 6 Repeat Steps 2 through 5 for the right side; finger tighten fasteners.

STEP 7 Install the backrest bar (not included) into the Mounting Straps as shown in PIC 3; secure backrest bar to Mounting Straps with fasteners (not included). Finger tighten at this time.

FIG 2



PIC 4



PIC 5



PIC 6



NOTE: With the fasteners loosely installed, adjust the Backrest Mounting Strap plates to accommodate the backrest bar.

STEP 8 Starting with the M10 X 1.25 X 53.5 Custom Head bolt (See PIC 6), tighten all of the fasteners; check for proper clearance and operation.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.