



L.E.D BAT LASHES FOR TOURING & TRIKE, CHROME

6904

Thank You For Choosing Kuryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right-Side Light Assembly
- 1 Right-Side Housing
- 1 Right-Side Gasket
- 1 Left-Side Light Assembly
- 1 Left-Side Housing
- 1 Left-Side Gasket
- 1 Front Accessory Wiring Harness
- 1 Hardware Kit containing:
 - 8 M3 X 6 Hi/Lo Screws
 - 6 #8-32 X .575 T-Screw
 - 4 3-Pin Connector, Male
 - 6 #8-32 Hex Flange Locknuts
- 1 Installation Instructions

YOU WILL ALSO NEED:


Warm, soapy water and a clean rag, masking tape, marker, center punch, drill and drill bits, set of Torx drivers, 11/32" open end wrench or socket and ratchet

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**. Allow the engine and exhaust system to cool. Remove the main fuse.

STEP 2 Refer to **PIC 1**. Locate the Left Chrome Housing and Gasket.



WARNING

THE END USER'S SAFETY DEPENDS UPON PROPER INSTALLATION OF THIS PRODUCT. IF A STEP IN THESE INSTRUCTIONS IS NOT WITHIN YOUR CAPABILITIES OR YOU DO NOT HAVE THE CORRECT TOOLS, HAVE YOUR DEALER PERFORM THE PROCEDURE. IMPROPER INSTALLATION OF THIS PRODUCT COULD RESULT IN DEATH OR SERIOUS INJURY.

ACCIDENTAL VEHICLE START-UP COULD CAUSE DEATH OR SERIOUS INJURY, REMOVE THE MAIN FUSE BEFORE PROCEEDING.

NOTICE

Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

STEP 3 Refer to **PIC 2**. Using warm soapy water and a clean rag, remove all dirt and debris from the outer fairing; allow the area to dry completely.

STEP 4 Position the clutch-side (left) Bat Lash as shown in **PIC 2**. Use masking tape to make alignment marks; use masking tape to temporarily hold the Bat Lash in place to make alignment easier.

Repeat for the brake-side (right) Bat Lash.

STEP 5 Refer to **PIC 3**. Use a marker to mark the center of each of the four (4) holes designated by an arrow.

Remove the Bat Lash; use a center punch to make a mark at each of the marker points.

Repeat for the other side; remove and discard the masking tape.

STEP 6 Refer to **PIC 4**. Remove the two screws from each side of the inner fairing; set them aside for now, they will be reused. Repeat for the other side.

Remove the three windshield screws; set them aside for now.

Carefully remove the outer fairing; unplug the headlight connector and set the outer fairing (headlight facing up) on a soft, sturdy surface.

NOTICE

MEASURE TWICE—DRILL ONCE. Double check all reference marks made on the fairing **BEFORE** drilling. Kuryakyn is not responsible for incidental or consequential damages resulting from this installation.






STEP 7 Drill 1/8" pilot holes in the outer fairing at the marks made in **STEP 5**. There will be a total of eight (8) holes in the outer fairing.

Enlarge the holes to 1/4".

STEP 8 Refer to **PIC 5**. Locate the clutch-side (Left) Bat Lash Assembly, Housing, and Gasket.

Route the wire from the Assembly through the Housing and Gasket as shown in **PIC 5**.

STEP 9 Locate the six included T-Screws. Insert the T-Screws through the holes designated by the arrows as shown in **PIC 6**. Ensure that the T-Screws align with the rectangular recesses; insert three (3) per side.




STEP 10 Locate six (6) of the included **M3 X 6 Hi/Lo Screws**; set them within arms reach of the work area. There are two extra Screws included.

Refer to **PIC 7**. Gently pull the wire through until the strain-relief collar locates in the hole in the Housing.

Secure the Assembly to the Housing with three of the Hi/Lo Screws.

Press the Assembly into the Housing as you start the three screws in the holes.


Repeat for the other side.



STEP 11 Refer to **PIC 8**. Press the Gasket into place in the back-side of the Housing;

ensure that the wire has been pulled all the way through the hole and the rubber collar remains in the hole.

Repeat for the other side.




STEP 12 Route the wires through the hole in the outer fairing; align and insert the T-Screws with the holes in the fairing;

On the backside of the outer fairing, secure the Bat Lash with the three included Hex Nuts: **DO NOT OVER TIGHTEN THE NUTS**.

Repeat for the other side.

STEP 13 Refer to **PIC 9**. Locate the included Front Accessory Wiring Adapter and the 2-pin accessory connector on upper corner of the brake-side (right) inner fairing.




STEP 14 Refer to **PIC 10**. Locate the included 3-Pin Connectors (Male).

Insert the 3-Pin Connector into the female connector from the Accessory Adapter;

insert the terminal from the **RED** Bat Lash wire into the connector across from the **RED** wire as shown in **PIC 10**.

Insert the **BLACK** wire across from the **BLACK** wire in the same manner.

Repeat for the other Bat Lash.





STEP 15 Reinstall the main fuse, turn the **IGN ON**, and test for proper function of the lights. The Bat Lashes are running lights. Turn **IGN OFF**.

STEP 16 Reconnect the headlight and reinstall the outer fairing and windshield in the reverse order they were removed.

WARNING

VISIBILITY IS A **MAJOR** CONCERN FOR MOTORCYCLISTS. A LIGHT MALFUNCTION COULD RESULT IN DEATH OR SERIOUS INJURY. ENSURE PROPER LIGHT OPERATION **BEFORE** RIDING THE MOTORCYCLE.

NOTICE

It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials & workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

1. Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
2. The product must be properly installed, maintained & operated under normal conditions.
3. Kuryakyn shall not be liable for any consequential & incidental damages, including labor & paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn & a customer.
4. Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
5. Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'s contained in components of Kuryakyn products will be warranted for defects in materials & workmanship for 3 years from the date of purchase whereas all other components shall be warranted for one (1) year.
6. Merchandise purchased directly from Internet auction sites or any other third party seller is considered sold as is & shall not carry a Kuryakyn warranty. All warranty claims must be directed to the original seller. If unsure please contact the seller to verify they are an authorized Kuryakyn retailer.

RETURN POLICY

Merchandise determined to be defective may be returned up to one year from the date of purchase. Returns must be processed through original seller. Returned merchandise for any other reason other than warranty claims must be in like new condition & subject to a 20% restocking fee. All returns are subject to inspection for determination of full or partial credit. Any returned part that shows evidence of being used or installed contrary to manufacturer's instructions, &/or subjected to improper handling, packaging or return shipping by the customer, will not be eligible for exchange, refund or warranty consideration. All returned electrical items will be inspected & tested. If electrical item is deemed functional, no credit will be issued & item will be returned. All sales are final on discontinued or closeout merchandise.